

AIM-D100-ES series DC Insulation Monitor

User Manual V1.2

Declaration

Please read this instruction carefully before using this product. All pictures, logos and symbols involved are owned by Acrel Co., Ltd. All or part of the content shall not be reproduced publicly without written authorization by non-company personnel.

Please read the instructions and precautions in this operation manual carefully before using this series of products. Acrel will not be responsible for personal injury or economic loss caused by ignoring the instructions in this operation manual.

The equipment is professional electrical equipment, any related operation, need to be carried out by special electrical technicians. Acrel is not responsible for personal injury or financial loss resulting from the error of non-professional personnel.

The contents of this description will be updated and amended constantly, and it is inevitable that there will be a slight discrepancy between the physical product and the description in the product function upgrading. Please refer to the physical product purchased and obtain the latest version of the description through www.acrel-electric.com or sales channels.

Modified Records

No.	Date	Version	Description
1	2023.09.10	V1.0	First version
2	2024.05.20	V1.1	Add ESL, modified power supply, power consumption, temperature; appearance size accurate to 0.1, communication add 06 examples, registers add 40H, 42H.
3	2024.12.14	V1.2	Update product image in the introduction
Notes:			

Contents

1 Introduction	1
2 Model Description	1
3 Functional Characteristics	1
4 Technical Parameters	2
5 Installation and Connection	2
5.1 Shape and Size	2
5.2 Installation	3
5.3 Wiring	3
5.4 Wiring Diagram	4
5.5 Attention	4
6 Programming and Usage	5
6.1 Panel Description	5
6.2 LED Indicator Instructions	5
6.3 DIP Switch Description	5
7 Communication Instruction	6
7.1 Communication Protocol	6
7.2 Function Code Introduction	7
7.3 Register Address Table	8
7.4 Register Operation Description	9
7.5 Message Example	10
8 Application	11

AIM-D100-ES series DC Insulation Monitor

1 Introduction




With the development of industry, many electrical equipment and factory equipment are powered by DC systems, and the positive and negative poles of the DC system are not grounded. For ungrounded (IT) power distribution systems, insulation resistance should be monitored to ensure the safe operation of the power supply system.

AIM-D100-ES series DC Insulation Monitor can be used in 15~1500V DC systems to monitor the positive and negative pole-to-ground insulation resistance of ungrounded DC systems online. When the insulation resistance is lower than the set value, it

will issue a pre-warning or alarm signal.

The product is mainly designed for insulation monitoring of energy storage systems in 15~1500V range. It can also be used in DC systems such as power plants, DC panels in substations, electric vehicle charging devices, UPS power supply systems, photovoltaic systems and other place.

2 Model Description



3 Functional Characteristics

- Resistance monitoring. The product can monitor the insulation resistance of the positive and negative poles of the DC system to the ground. When the insulation resistance is lower than the set warning and alarm values, it can send out warning and alarm signals.
- Voltage monitoring. The product can monitor the voltage between the positive and negative poles of the DC system and the voltage between the positive and negative poles with respect to ground. The measurement range is 15~1500V.
- LED indication. The product panel has operation, communication, and fault LED indicators.
- Communication. The product has RS485 interface and adopts Modbus-RTU protocol.
- Metal casing. The product adopts a metal shell and can be wall-mounted or guide rails-mounted.
- Plug-in terminals. The product adopts plug-in terminal wiring, which is convenient.


4 Technical Parameters

Technical Parameter		Technical Specifications	
		AIM-D100-ESL	AIM-D100-ES
Auxiliary power		DC 12~36V	
Maximum power consumption		≤3W	
Voltage monitor	Voltage range	DC 15~150V	DC 150~1500V
	Accuracy	0.5	
Insulation monitoring	Insulation resistance range	1kΩ~10MΩ	
	Warning and alarm range	10kΩ~10MΩ	
	Accuracy	1~10kΩ: ±1k; 10k~500k: ≤3%	
	System leakage capacitance	≤5μF	
	Insulation monitoring speed	500ms/cycle; 1000ms/cycle	
Alarm method		LED indicator	
Communication		RS485 interface, Modbus-RTU protocol	
Installation		Wall-mounted installation or DIN-rail installation (plastic stent included)	
Protection level		IP30	
Environment	Operating temperature	-20~+60°C	
	Storage temperature	-25~+75°C	
	Relative humidity	<95%, without condensation	
	Altitude	<2000m	

5 Installation and Connection

5.1 Shape and Size

The overall dimensions are shown in the figure below. (Unit: mm)



Appearance

Front view


Side view

Installation dimensions

5.2 Installation

First installation method: wall-mounted installation. When installing the product, use the two M3 self-tapping screws (or other screws) provided with the product to pass through the mounting holes on both sides of the instrument and fix it to the bracket in the cabinet or the galvanized metal plate.

Second installation method: guide rail installation. When installing the product, first clamp the plastic bracket that comes with the product on the guide rail. Align the mounting holes on both sides of the instrument with the plastic bracket mounting holes. Use the 4 included M3 self-tapping screws to align the mounting holes and tighten them. The guide rail installation is as follows As shown in the figure.



5.3 Wiring

The wiring terminals of the AIM-D100-ES series DC Insulation Monitor product are shown in the figure below:

1	2	3	3	11	11	14	14	21	22
24V	G	PE	PE	DC+	DC+	DC-	DC-	A	B
Power		Ground		Positive		Negative		RS485	

Description:

Terminal 1 and 2: Connect to DC 24V power supply;

Terminal 3: Connect to the on-site grounding bar, the terminals are connected inside and can be wired from either terminal.

Terminal 11: Connect to the positive pole of the DC system, the terminals are connected inside and can be wired from either terminal.

Terminal 14: Connect to the negative pole of the DC system, the terminals are connected inside and can be wired from either terminal.


Terminal 21 and 22: RS485 interface.

Wiring Specification:

For auxiliary power supply, functional grounding, and DC system positive and negative wiring,

1.5mm² multi-core copper wires can be used. RS485 communication wiring can use 0.75~1.5mm² shielded twisted pair.

5.4 Wiring Diagram



5.5 Attention

(1) When designing and installing insulation monitors, it should be noted that only one insulation monitor can be installed in a system. If multiple insulation monitors are installed in different locations of the same system, a control strategy should be used for insulation resistance monitoring.

(2) The insulation monitor can be installed in the distribution box, and the installation location is free of dripping water, corrosive chemical gases, and sedimentation substances.


(3) When wiring the insulation monitor, you should strictly follow the wiring diagram. It is best to use a pin socket connector for crimping, then insert the instrument terminal and tighten the screws to avoid abnormal operation of the instrument due to poor contact.

(4) The insulation monitor should be reliably connected to the DC system being monitored to ensure the effectiveness of insulation monitoring.

(5) Non-professionals are strictly prohibited from opening the product casing without authorization to avoid affecting product functions.

6 Programming and Usage

6.1 Panel Description



6.2 LED Indicator Instructions

Indicator	Function Description
On	When the instrument is running normally, the indicator light flashes with a flashing frequency of approximately once per second.
Comm	When there is no data communication, the indicator light is off. When there is data communication, the indicator light flashes.
Fault	The indicator light flashes when an insulation fault occurs and is always on when an insulation fault occurs.

6.3 DIP Switch Description

There are 8-digit DIP switches on the upper terminals of the AIM-D100-ES series DC Insulation Monitor. The functions corresponding to each group of DIP switches are as shown in the table below:

BAUD1	BAUD2	Baud rate	ADD1	ADD2	ADD3	ADD4	ADD5	ADD6	Communication address	
0	0	4800	0	0	0	0	0	1	1	
0	1	9600	0	0	0	0	1	0	2	
1	0	19200
1	1	38400	1	1	1	1	1	1	63	

Notes: 1: on 0: off

The combination of BAUD1 and BAUD2 DIP switch: used to set the baud rate of RS485 communication. The factory default value is 01.

The combination of ADD1~ADD6 DIP switch: used to set the address of the instrument's RS485

communication. The calculation method is based on binary calculation. For example: when ADD1~ADD6 are all 1, that is, 111111 is 63, the calculation method is: $1*2^5+1*2^4+1*2^3+1*2^2+1*2^1+1*2^0=63$. When the corresponding position is 0, there is no need to calculate, such as 000001, the calculation method is: $0*2^5+0*2^4+0*2^3+0*2^2+0*2^1+1*2^0=1$, only the last digit needs to be calculated, that is $1*2^0=1$. The default value is 000001, the default is 1.

7 Communication Instruction

7.1 Communication Protocol

The RS485 interface of the instrument adopts the Modbus-RTU communication protocol. The protocol defines the address, function code, data, check code, etc. in detail, which is a necessary content to complete the data exchange between the host and the slave.

7.1.1 Transmission method

Information transmission is asynchronous and in bytes. The communication information transmitted between the host and the slave is in an 11-bit format, including 1 start bit, 8 data bits (the smallest significant bit is sent first), and no Parity bit, 1 stop bit (N-8-1).

7.1.2 Information frame format

Address Code	Function Code	Data Zone	CRC check code
1Byte	1 Byte	n Byte	2 Byte

Address code: The device address code is at the beginning of the data frame and consists of one byte (8-bit binary code), ranging from 0 to 255 in decimal. The device can set the address to 1 to 247. These bits identify the address of the user-specified end device that will receive data from the connected host. The address of each terminal device must be unique, and only the addressed terminal will respond to a query containing this address. When the terminal sends back a response, the slave address data in the response tells the host which terminal it is communicating with.

Function code: The function code indicates what function the addressed terminal performs.

Function Code	Definition	Explanation
03H/04H	Read data register	Get the current binary value
06H	write single registers	Set binary values to single registers
10H	Write multiple registers	Set binary values to multiple registers

Data zone: The data area contains the data required by the terminal to perform specific functions or the data collected when the terminal responds to queries. The content of these data may be numerical values, reference addresses or setting values. For example: the function code tells the terminal to read a register, and the data zone needs to indicate which register to start from and how much data to read. The embedded address and data vary according to the type and content between slaves.◦

CRC check code: The error check (CRC) field occupies two bytes and contains a 16-bit binary value. The CRC value is calculated by the transmitting device and then appended to the data frame.

The receiving device recalculates the CRC value when receiving the data and then compares it with the value in the received CRC field. If the two values are not equal, it occurs. mistake.

7.2 Function Code Introduction

7.2.1 Function code 03H or 04H: Read register

This function allows users to obtain data and system parameters collected and recorded by the device. There is no limit to the number of data requested by the host at one time, but it cannot exceed the defined address range.

The following example reads data from the 00 25H register from the slave at address 01.

Host send		Sent information	Slave return		Returned information
Address code		01H	Address code		01H
Function code		03H	Function code		03H
Starting address	High byte	00H	Byte count		02H
	Low byte	25H	Register data	High byte	1FH
Register count	High byte	00H		Low byte	68H
	Low byte	01H	CRC check code	Low byte	B1H
CRC check code	Low byte	95H		High byte	9AH
	High byte	C1H			

The slave returns a read result of 0x1F68H, decimal 8040, indicating a system voltage of 804V.

7.2.2 Function code 06H: Write single registers

Function code 06H allows the user to change the contents of a single register without going outside the defined address range.

The following example writes 0xEF EF data to the 0034H register of the slave at address 01.

Host send		Sent information	Slave return		Returned information
Address Code		01H	Address Code		01H
Function Code		06H	Function Code		06H
Register address	High byte	00H	Register address	High byte	00H
	Low byte	34H		Low byte	34H
Data to be written	High byte	EFH	Data to be written	High byte	EFH
	Low byte	EFH		Low byte	EFH
CRC check code	Low byte	C5H	CRC check code	Low byte	C5H
	High byte	B8H		High byte	B8H

The host writes 0xEF EF to 00 34H to indicate that the insulation alarm switch is turned on.

7.2.3 Function Code 10H: Write Multiple Registers

Function code 10H allows the user to change the contents of multiple registers without going outside the defined address range.

The following example writes 0xFEFE, 0x0064, 0x0032 to the 0034H~0036H registers of the slave at address 01.

Host send		Sent information	Slave return		Returned information
Address Code		01H	Address Code		01H
Function Code		10H	Function code		10H
Starting address	High byte	00H	Starting address	High byte	00H
	Low byte	34H		Low byte	34H
Register count	High byte	00H	Register count	High byte	00H
	Low byte	03H		Low byte	03H
Register count		06H	CRC check code	Low byte	C1H
0004H Data to be written	High byte	FEH		High byte	C6H
	Low byte	FEH			
0005H Data to be written	High byte	00H			
	Low byte	64H			
0006H Data to be written	High byte	00H			
	Low byte	32H			
CRC check code	Low byte	5BH			
	High byte	AAH			

The host writes 0xFEFE, 0x0064, 0x00 32H to 00 34H~00 36H to indicate that the insulation alarm switch is turned on, setting warning value of 100kΩ and alarm value of 50kΩ.

Note: The above data is for reference only. Please refer to the address table for register definitions.

7.3 Register Address Table

No.	Address	Parameter	Read /Write	Value range	Data Types
0	00H	Reserved	R		UINT16
1	01H	Communication address	R	1~63 (default 1)	UINT16
2	02H	Baud rate	R	0~3: 4800, 9600, 19200, 38400 (Unit: bps) (default 1)	UINT16
3~11	03H~0BH	Reserved	R		UINT16*9
12	0CH	Software number	R		UINT16
13	0DH	Software version	R		UINT16
14~31	0EH~1FH	Reserved	R		UINT16*18
32	20H	Fault type	R	bit15: 1 DC+ and DC- connected reversely; 0 is normal	UINT16

				bit14~bit6: Reserved bit5: 1 negative pole insulation fault warning; 0 is normal bit4: 1 negative pole insulation fault alarm; 0 is normal bit3: 1 positive pole insulation fault warning; 0 is normal bit2: 1 positive pole insulation fault alarm; 0 is normal bit1~bit0: Reserved 00 18 means 0000 0000 0001 1000	
33	21H	Positive pole insulation resistance	R	Unit: kΩ; Ratio is 1	UINT16
34	22H	Negative pole insulation resistance	R	For example, 10000, the resistance is 10MΩ	UINT16
35	23H	Positive pole voltage to ground	R	Unit: V; Ratio is 0.1	UINT16
36	24H	Negative pole voltage to ground	R	For example, 4567, the voltage is 4567*0.1=456.7V	UINT16
37	25H	System voltage	R	Unit: V; Ratio is 0.1	UINT16
38	26H	Reserved	R		UINT16
39~51	27H~33H	Reserved	R		UINT16*13
52	34H	Insulation alarm switch	R/W	0xFEFE is on (default is on) 0xEFEF is off	UINT16
53	35H	Positive pole insulation resistance warning value	R/W	10~10000kΩ (default 100)	UINT16
54	36H	Positive pole insulation resistance alarm value	R/W	10~10000kΩ (default 50)	UINT16
55	37H	Negative pole insulation resistance warning value	R/W	10~10000kΩ (default 100)	UINT16
56	38H	Negative pole insulation resistance alarm value	R/W	10~10000kΩ (default 50)	UINT16
57~62	39H~3EH	Reserved	R		UINT16*6
63	3FH	Insulation monitor speed	R/W	0:500ms/cycle; 1:1000ms/cycle	UINT16
64	40H	Insulation monitor trigger mode	R/W	0x01: Cycle; 0x10: Communication (default 10)	UINT16
65	41H	Capacitor delay time	R/W	0~60000ms (default 0)	UINT16
66	42H	Resistances monitor delay time	R/W	5~500s (default 5s)	UINT16

7.4 Register Operation Description

7.4.1 Insulation Monitoring Trigger Mode

0x40H is the insulation monitoring trigger form, there are three main types: cycle trigger, communication trigger, cycle and communication trigger, default cycle trigger.

Cycle trigger form, timed monitoring, monitoring time 500ms or 1000ms once, after monitoring update register data, after a polling delay (0x42H), continue to trigger monitoring. After a polling delay (0x42H), the monitoring will continue to be triggered. The host communication reads 0x20H~0x24H register data, and the instrument returns the latest data in the register.

Communication trigger form, polling delay (0x42H) is invalid, insulation monitoring in standby mode. Host communication read 0x20H~0x24H register data, the instrument triggers a monitoring, monitoring time 500ms or 1000ms once, monitoring register data refresh and return data, monitoring time repeated reading data is invalid, not monitoring can not return data. It is recommended that the interval between two readings when communication is triggered is more than 2500ms, and the timeout time is more than 1500ms.


7.4.2 Insulation Monitoring Speed

0x3FH is the insulation monitoring resistance time, and the insulation monitoring period can be set to 500ms or 1000ms. The accuracy of 500ms is slightly worse.

7.4.3 Delay Time of Insulation Monitoring Capacitor

0x41H is the insulation monitoring capacitance time. When the system capacitance is $>5\mu\text{F}$, the insulation resistance monitoring has a long response time and the insulation monitoring accuracy deteriorates. You can set the insulation monitoring capacitance time to 1000ms/10 μF and increase the monitoring time to stabilize the insulation measurement and eliminate the influence of capacitance.

The cycle trigger defines polling delay as T_d , insulation monitoring resistance time as Δt , insulation monitoring capacitance time as Δt_F ; the communication trigger defines reading interval time as T_c , and timeout as T_o . The time correspondence is shown in the following figure:



7.5 Message Example

7.5.1 Read the insulation monitoring status

Host Send: **01 03 00 20 00 05 84 03**

Slave Response: **01 03 0A 00 18 00 64 00 0A 11 94 01 C2 F7 A0**

Data Analysis: 00 18 represents the fault type, the binary system is 0000 0000 0001 1000, the fault is positive insulation fault warning, negative insulation fault alarm; 00 64 represents the positive pole to ground insulation resistance, 100k Ω ; 00 0A represents the negative pole to ground insulation resistance, 10k Ω ; 11 94 represents the positive electrode to ground voltage, 4540/10=454.0V; 01 C2 represents the negative electrode to ground voltage, 450/10=45.0V.

7.5.2 Read the system voltage status

Host Send: 01 03 00 25 00 01 95 C1

Slave Response: 01 03 02 1F 68 B1 9A

Data Analysis: 1F 68 represents the system voltage, $8040/10=804V$.

7.5.3 Set Alarm Parameters

The alarm switch is turned on by default, the positive and negative insulation fault warning values default to $100k\Omega$, and the positive and negative insulation fault alarm values default to $50k\Omega$. No changes are required without special requirements. If you need to change, please refer to the following example.

(1) Turn on the alarm switch

Host Send: 01 06 00 34 FE FE 09 E4

Slave Response: 01 06 00 34 FE FE 09 E4

(2) Turn off the alarm switch

Host Send: 01 06 00 34 EF EF C5 B8

Slave Response: 01 06 00 34 EF EF C5 B8

(3) Alarm threshold setting

Host send: 01 10 00 35 00 04 08 00 64 00 32 00 64 00 32 26 3E


Slave response: 01 10 00 35 00 04 D1 C4

Data analysis: 00 64 means setting the positive insulation fault alarm value to $100k\Omega$; 00 32 means setting the positive insulation fault alarm value to $50k\Omega$; 00 64 means setting the negative insulation fault alarm value to $100k\Omega$; 00 32 means setting the negative insulation fault alarm value to $50k\Omega$.

8 Application

The principle of mounting insulation monitors is to use one insulation monitor for the same stand-alone system; when more than one insulation monitor is used, they can interfere with each other and affect the monitoring. Insulation monitors can be used in energy storage systems to monitor the insulation of individual battery clusters as well as the overall insulation. In the energy storage system, the main control module is used to control the working status of each insulation monitor, and the time-sharing control strategy is adopted to ensure that only one insulation monitor is in working status at the same time, and that the insulation monitors do not interfere with each other, and at the same time to ensure that the energy storage system can carry out insulation monitoring at all times, so as to guarantee the safety, stability and reliability of the system.

The following figure shows the application example of AIM-D100-ES DC insulation monitor in energy storage system.



Notes: BP stands for Battery Pack; PCS stands for Power Conversion System; BCM stands for Battery Control Module.

Headquarters: Acrel Co., LTD.

Address: No.253 Yulv Road Jiading District, Shanghai, China

TEL.: 0086-21-69158338 0086-21-69156052 0086-21-59156392 0086-21-69156971

Fax: 0086-21-69158303

Web-site: www.acrel-electric.com

mail: ACREL008@vip.163.com

Postcode: 201801

Manufacturer: Jiangsu Acrel Electrical Manufacturing Co., LTD.

Address: No.5 Dongmeng Road, Dongmeng industrial Park, Nanzha Street, Jiangyin City, Jiangsu Province, China

TEL: 0086-510-86179966

Fax: 0086-510-86179975

Web-site: www.jsacrel.com

Postcode: 214405

E-mail: sales@email.acrel.cn